



ModelFitter

Getting started with the ModelFitter for Excel

Working with examples

Overview Excel Tool

Data

- Database
- Simulation results

Fitting History

Backup of former values

Differential States

Important user input for Differential State Variables



Main

- Settings
- Control Bar
- Parameters
- Statistics
- Main plots

Plots

Illustration of the results in different plot types


Help

Short explanations of all terms and functionalities



Help

The Help tab provides explanations of terms and functionalities which are used within the ModelFitter.



Data

Simulation results

Beside the Database simulation results are shown:

- **Simulation Output**
- **Output Residuals:** Calculated residuum between simulation output and dependents
- **Simulation Output (Additional):** Possible additional outputs

Data Points



TLK-Thermo GmbH

Simulation Output (Dependent Variables)

| m_flow | P |
|-------------------|-----------------|
| comp.portA_m_flow | comp.shaftPower |
| kg/s | W |
| 9,825E-02 | 3,932E+03 |
| 1,764E-01 | 1,695E+04 |
| 4,545E-02 | 2,213E+03 |
| 1,915E-01 | 1,697E+04 |
| 5,163E-02 | 1,176E+03 |
| 3,826E-02 | 1,370E+03 |
| 1,329E-01 | 7,352E+03 |
| 1,620E-01 | 1,424E+04 |
| 2,042E-01 | 2,083E+04 |
| 4,320E-02 | 1,160E+03 |
| 1,588E-01 | 1,468E+04 |
| 2,052E-01 | 1,743E+04 |
| 2,351E-01 | 2,106E+04 |
| 1,561E-01 | 1,819E+04 |
| 1,968E-01 | 1,284E+04 |
| 7,835E-02 | 5,783E+03 |
| 4,138E-02 | 2,630E+03 |
| 1,221E-01 | 5,077E+03 |
| 1,321E-01 | 1,116E+04 |
| 2,362E-01 | 1,775E+04 |
| 1,574E-01 | 1,439E+04 |
| 4,278E-02 | 2,628E+03 |
| 3,219E-02 | 1,830E+03 |
| 8,308E-02 | 6,583E+03 |
| 1,617E-01 | 9,253E+03 |

Output Residuals

| m_flow | P |
|------------|------------|
| kg/s | W |
| -3,324E-02 | -7,392E+01 |
| -1,104E-01 | -5,931E+03 |
| -1,015E-02 | -7,242E+01 |
| -1,200E-01 | -6,362E+03 |
| -8,884E-03 | 1,465E+01 |
| -7,722E-03 | 5,495E+01 |
| -6,672E-02 | -1,491E+03 |
| -9,477E-02 | -4,197E+03 |
| -1,274E-01 | -7,453E+03 |
| -7,179E-03 | 6,902E+01 |
| -9,309E-02 | -4,360E+03 |
| -1,286E-01 | -7,297E+03 |
| -1,459E-01 | -7,750E+03 |
| -9,765E-02 | -6,342E+03 |
| -1,148E-01 | -4,354E+03 |
| -2,762E-02 | -4,850E+02 |
| -1,073E-02 | -9,549E+01 |
| -4,292E-02 | -2,398E+02 |
| -6,533E-02 | -2,232E+03 |
| -1,471E-01 | -7,586E+03 |
| -9,891E-02 | -5,419E+03 |
| -1,195E-02 | -3,318E+01 |
| -7,427E-03 | -3,887E+01 |
| -3,041E-02 | -7,345E+02 |
| -7,993E-02 | -1,767E+03 |

Simulation Output (Additional)

| speed | eta |
|-----------------|----------------------|
| mmary.speed_rpm | omp.summary.effIsEff |
| 1/min | 1 |
| 2,500E+03 | 6,388E-01 |
| 7,000E+03 | 5,406E-01 |
| 1,000E+03 | 8,664E-01 |
| 7,000E+03 | 4,304E-01 |
| 1,000E+03 | 7,846E-01 |
| 1,000E+03 | 8,317E-01 |
| 4,000E+03 | 5,381E-01 |
| 5,500E+03 | 5,977E-01 |
| 7,000E+03 | 5,423E-01 |
| 1,000E+03 | 7,953E-01 |
| 5,500E+03 | 6,588E-01 |
| 7,000E+03 | 2,515E-01 |
| 7,000E+03 | 5,187E-01 |
| 7,000E+03 | 6,079E-01 |
| 5,500E+03 | 3,023E-01 |
| 2,500E+03 | 8,204E-01 |
| 1,000E+03 | 8,705E-01 |
| 2,500E+03 | 6,951E-01 |
| 4,000E+03 | 7,394E-01 |
| 7,000E+03 | 2,378E-01 |
| 7,000E+03 | 3,801E-01 |
| 1,000E+03 | 8,646E-01 |
| 1,000E+03 | 8,573E-01 |
| 2,500E+03 | 8,346E-01 |
| 4,000E+03 | 5,574E-01 |

info@tlk-thermo.de
www.tlk-thermo.de

Main

Settings

Settings for the fitting process

Control Bar

- Fit Control
- Change Model
- Dynamic Simulation

Fitting Targets

Parameters

Fitting Parameters

Simulation vs. Data

Main plots (Dependents)

Model-Fitter for TIL_ReciprocatingCompressor

Settings

File/Name: C:\Program Path and name of the Model
 maxIterations: 20 Number of the Levenberg-Marquardt-Iterations
 tStop: 100 Stop time for integration
 printStats: Write additional messages
 dxdTolerance: 1.00E-07 Steady state condition
 diffStep: 1.00E-05 Stepsize for numeric differentiation
 epsf: 1.00E-50 Minimal change of the fitting target residuals
 epsg: 1.00E-50 Minimal change of the gradient
 epsx: 1.00E-50 Minimal change of the fitting parameter

Control Bar

Fit Control | Change Model | Dynamic Simulation

Fit 1 Step | Fit | Change File | Create Charts | Create Simulation
 Calculate | Show Log Window

Parameters

| Fit | Index | Alias | Name | Value | Unit | Min | Max | Nominal |
|-----|-------|----------------|------------------|-----------|----------------|-----------|-----------|-----------|
| ✓ | 1 | SuctionArea | suctionValve | 1.464E-05 | m ² | 1.000E-10 | 1.000E-03 | 1.000E-05 |
| ✓ | 2 | Leakage | sealLeakage | 6.181E-05 | m ² | 0.000E+00 | 1.000E-03 | 1.000E-05 |
| ✓ | 3 | DischargeArea | dischargeValve | 5.387E-03 | 1 | 0.000E+00 | 1.000E-01 | 1.000E-02 |
| ✓ | 4 | DischargeDisby | zValveDisby | 2.464E-04 | z | 0.000E+00 | 1.000E-02 | 1.000E-04 |
| ✓ | 5 | DischargeArea | chargeValve | 5.747E-06 | m ² | 1.000E-10 | 1.000E-03 | 6.000E-06 |
| ✗ | 6 | plInitialLow | initialSuction | 1.000E+06 | Pa | | | |
| ✗ | 7 | plInitialHigh | initialDischarge | 8.000E+06 | Pa | | | |
| ✗ | 8 | x | x | 1.000E+00 | 1 | | | |
| ✗ | 9 | | | | | | | |

Statistics

Determinant: 1.02E+57

Correlation Matrix

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | |
|---|----------|----------|-------|-------|-------|-------|-------|------|------|------|
| 1 | 1.000 | -0.03 | 0.03 | 0.32 | -0.74 | | | | | |
| 2 | 2.82E-07 | 1.92E-02 | | | | | | | | |
| 3 | 1.53E-08 | 2.49E-01 | -0.03 | 1.00 | -0.88 | 0.26 | 0.16 | | | |
| 4 | 4.07E-03 | 7.94E-01 | 0.03 | -0.83 | 1.00 | -0.34 | -0.12 | | | |
| 5 | 1.39E-04 | 5.62E-01 | 0.32 | 0.26 | -0.34 | 1.00 | -0.65 | | | |
| 6 | 3.25E-07 | 5.65E-02 | -0.74 | 0.16 | -0.12 | -0.65 | 1.00 | | | |
| 7 | | | | | | | | 1.00 | | |
| 8 | | | | | | | | | 1.00 | |
| 9 | | | | | | | | | | 1.00 |

Fitting Targets

Include Alias

| Alias | R ² | RMSE |
|--------|----------------|---------------------|
| m_flow | 0 | 0.000E+00 8.315E-02 |
| P | 1000 | 0.000E+00 4.188E+03 |

Simulation vs. Data

m_flow

P

Version 1.0

info@tlk-thermo.de
www.tlk-thermo.de

Statistics

Main

Control Bar – Fit Control

Fit 1 Step

- Only 1 step
- several times Fit1Step is not the same as a complete fit with several steps
- New fitting parameters
- See also fitting history

Calculate


- Calculates the included static data points [s. Data Tab]
- Outputs are simulation results and some statistics
- No fitting

Fit

- Complete fit
- Number of steps: maxiterations
- New fitting parameters
- See also fitting history

Show Log Window

- Shows messages from the ModelFitter
- Pops up automatically
- After closing, reopen with button „Show Log Window“





Main

Control Bar – Change Model


Change File

Change the input file (FMU)

Create Charts

- Re-draw all charts

See documentation of „How to Change Model“ for changing the Excel Tool to fit other models.





Main

Settings

Most important settings

- **printStats:**
Additional information about the performance of the fitting process are written into the log window
- **maxIterations:**
Maximum number of steps the ModelFitter does to improve the fitting parameters
- **dxdTolerance:**
Global tolerance for the change of differential state variables during steady state

| Settings | | |
|---------------|-------------------------------------|--|
| FileName | C:\Program F | Path and name of the Model |
| printStats | <input checked="" type="checkbox"/> | Write additional messages |
| maxIterations | 20 | Number of the Levenberg-Marquard-Iterations |
| dxdTolerance | 1,00E-07 | Steady state condition |
| diffStep | 1,00E-05 | Stepsize for numeric differentiation |
| epsf | 1,00E-50 | Minimal change of the fitting target residuals |
| epsg | 1,00E-50 | Minimum of the gradient |
| epsx | 1,00E-50 | Minimal change of the fitting parameter |
| tStop | 100 | Stop time for integration |

Please consider to adjust the settings only if problems occur.

Main

Parameters

Fitting parameters:

- Have to be marked →
- The name of the full variable path is needed, e.g. „*comp.areaSuctionValve*“
- Start with meaningful values

Fixed parameters:

Parameters that are marked with a red cross are assigned as fixed parameters during simulation.

| Fit | Index | Alias | Name | Value Unit | Min | Max | Nominal |
|-----|-------|----------------|---------------------|--------------------------|-----------|-----------|-----------|
| ✓ | 1 | SuctionArea | SuctionValve | 1,464E-05 m ² | 1,000E-10 | 1,000E-03 | 1,000E-05 |
| ✓ | 2 | Leakage | areaLeakage | 6,181E-08 m ² | 0,000E+00 | 1,000E-03 | 1,000E-06 |
| ✓ | 3 | DeadSpace | DeadSpace | 5,387E-03 1 | 0,000E+00 | 1,000E-01 | 1,000E-02 |
| ✓ | 4 | DischargeDelay | DischargeValveDelay | 2,464E-04 s | 0,000E+00 | 1,000E-02 | 1,000E-04 |
| ✓ | 5 | DischargeArea | DischargeValve | 5,747E-06 m ² | 1,000E-10 | 1,000E-03 | 6,000E-06 |
| ✗ | 6 | pInitialLow | InitialSuction | 1,000E+06 Pa | | | |
| ✗ | 7 | pInitialHigh | InitialDischarge | 8,000E+06 Pa | | | |
| ✗ | 8 | x | x | 1,000E+00 1 | | | |
| ✗ | 9 | | | | | | |

Main

Statistics

Sigma:

„How near are the current values of the fitting parameters to the optimum?“

Correlation Matrix:

„How does the fitting parameters influence each other?“

Determinant:

„How well does the database (e.g. measurement plan) fit to the model compared to other databases?“

Statistics

Determinant: Correlation Matrix

| σ | $\sigma_{\text{normalized}}$ | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|----------|------------------------------|-------|-------|-------|-------|-------|---|---|---|---|
| 2,82E-07 | 1,92E-02 | 1,00 | -0,03 | 0,03 | 0,92 | -0,74 | | | | |
| 1,53E-08 | 2,48E-01 | -0,03 | 1,00 | -0,89 | 0,26 | 0,16 | | | | |
| 4,07E-03 | 7,56E-01 | 0,03 | -0,89 | 1,00 | -0,34 | -0,12 | | | | |
| 1,39E-04 | 5,62E-01 | 0,92 | 0,26 | -0,34 | 1,00 | -0,65 | | | | |
| 3,25E-07 | 5,65E-02 | -0,74 | 0,16 | -0,12 | -0,65 | 1,00 | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |



Main

Statistics

R²:

„How well does the fitting parameters hit the database?“

RMSE:

„How big is the variation of the residuals?“

(residuals = dependent – simulation output)

| Statistics | |
|----------------|-----------|
| R ² | RMSE |
| 0,000E+00 | 8,313E-02 |
| 0,000E+00 | 4,188E+03 |




Differential State Variables

The steady state definition is mainly influenced by the values given here.

Cumulating and ineffectual differential state variables are marked with a red cross.

Differential State Variables




Differential State Variables

Of some specific differential state variables the differentiation cannot be brought to zero ("**cumulating Variables**"). In this case, those variables has to be marked for being ignored while the fitter tries to bring the rest of the differential states to zero. Otherwise the fitter could not come to stady state.
Autodetect is a function to detect recommended nominal values of the differential state variables. Additionally, the exclusion of the state variables that should be ignored is automatically executed.

Use as

| State Variable | Name | Unit | Min | Max | Nominal |
|----------------|---|------|------------|-----------|----------|
| ✓ | comp.suctionChamberVLEFluid.p | | 0,00E+00 | 1,00E+300 | 1,00E+06 |
| ✓ | comp.dischargeChamberVLEFluid.p | | 0,00E+00 | 1,00E+300 | 7,99E+06 |
| ✓ | comp.portA.h_outflow | | -1,00E+300 | 1,00E+300 | 3,50E+05 |
| ✓ | comp.portB.h_outflow | | -1,00E+300 | 1,00E+300 | 3,50E+05 |
| ✗ | comp.getInputsRotary.rotatoryFlange.phi | | -1,00E+300 | 1,00E+300 | 1,00E-03 |

Version 1.0

info@tlk-thermo.de
www.tlk-thermo.de 



Plots

Outputs vs. Inputs:

Here the mass flow rate in the simulation rises too high compared with the dependent with respect to the speed (independent).

Residuals vs. Inputs:

Same conclusion. Residual between simulation output and dependent grows with higher speed.



● Data Dependent ● Simulation Output



History

In case of a Fit, a Fit1Step or essential changes of the differential state variables, information are saved in the fitting history.

History of Fitting Parameter

Clear All

Fit One Step

| Time Stamp | Fit | Index | Alias | Name | Start Value | Fitted Value | Unit | $\sigma_{normalized}$ | Dependents | R ² | RMSD | Target |
|---------------------|-----|-------|----------------|---------------------|-------------|--------------|----------------|-----------------------|------------|----------------|-----------|--------|
| 15.06.2016 13:46:23 | 1 | 1 | SuctionArea | SuctionValve | 1,464E-05 | 7,744E-06 | m ² | 1,92E-02 | m_flow | 0,000E+00 | 8,313E-02 | 1 |
| | 1 | 2 | Leakage | AreaLeakage | 6,181E-08 | 2,383E-07 | m ² | 2,48E-01 | P | 0,000E+00 | 4,188E+03 | 1 |
| | 1 | 3 | DeadSpace | DeadSpace | 5,387E-03 | 1,241E-02 | 1 | 7,56E-01 | | | | |
| | 1 | 4 | DischargeDelay | DischargeValveDelay | 2,464E-04 | 2,449E-04 | s | 5,62E-01 | | | | |
| | 1 | 5 | DischargeArea | DischargeValve | 5,747E-06 | 5,306E-06 | m ² | 5,65E-02 | | | | |
| | 0 | 6 | pInitialLow | InitialSuction | 1,000E+06 | 1,000E+06 | Pa | | | | | |
| | 0 | 7 | pInitialHigh | InitialDischarge | 8,000E+06 | 8,000E+06 | Pa | | | | | |
| | 0 | 8 | x | | x | 1,000E+00 | 1,000E+00 | 1 | | | | |

Thank you

If you have any questions,
please don't hesitate to contact us at
modelfitter@tlk-thermo.com

Or your contact person
Jonathan Kistner
j.kistner@tlk-thermo.com



TLK-Thermo GmbH
Hans-Sommer-Str. 5
38106 Braunschweig
www.tlk-thermo.com

Tel.: +49/531/390 76 - 250
Fax: +49/531/390 76 - 29